

# MS Series Actuators for 11/4", 11/2" & 2" SV Series valves <u>Electrical Diagrams</u> for 24VAC or 24VDC




#### **MODEL NUMBERS**

#### **FOR 24VAC OR 24DC ACTUATORS**


# **MS1320, MS1320S** 88in/lb, 24VAC or 24VDC

### 2 WIRE, CAPACITOR RETURN, ON/OFF, FAIL SAFE ACTUATOR



# **MS1330** 88in/lb, 24VAC or 24VDC

# 3 WIRE CONSTANT POWER ON/OFF, FAIL LAST POSITION ACTUATOR WITH 2 POINT CONTROL (6 SECOND TRAVEL)



Valve actuator starting position can be factory set up on demand as either OPEN or CLOSED. If the valve is set-up in the open position the closing of the switch will drive it to the alternate position, and vice versa.

The starting position can be changed onsite by rotating the actuator 90° on the linkage.